


# Check Valve Flow Rate Chart



## Spring Check Valve Pressure Drop



127 Village Lane  
Easley, SC 29642

p: (864)605-0150  
f: (864)605-0830

www.tru-flo.com  
sales@tru-flo.com