


Check Valve Flow Rate Chart



Spring Check Valve Pressure Drop



127 Village Lane
Easley, SC 29642

p: (864)605-0150
f: (864)605-0830

www.tru-flo.com
sales@tru-flo.com