



TORQUE TABLE (Double Acting)

DOUBLE ACTING	AIR SUPPLY				
TYPE	40 PSIG	60 PSIG	80 PSIG	100 PSIG	120 PSIG
UT-11/12	62	94	125	156	187
UT-14/16	137	206	275	344	412
UT-17	180	270	360	450	540
UT-19/21	250	375	500	625	750
UT-26	375	562	750	937	1125
UT-31	500	750	1000	1250	1500
UT-36	800	1200	1600	2000	2400
UT-41	1000	1500	2000	2500	3000
UT-46	1562	2344	3125	3906	4687
UT-51	2250	3375	4500	5625	6750
UT-56	3000	4500	6000	7500	9000
UT-61	4550	6825	9100	11375	13650
UT-66	6000	9000	12000	15000	18000